

THE ENFORCER

User Manual - Flashlight DVR

Version No.: 1.5


The descriptions included are subject to minor change without notice.



Please read this user manual carefully before using the product. Failure to understand operation procedures may result in injury.

PACKING LIST:

- ① Flashlight DVR x 1
- ② USB Cable x 1
- ③ Software CD x 1
- ④ Power Adapter x 1
- ⑤ Safety Strap x 1
- ⑥ Lithium Battery x 1



These photos are for reference only. Please refer to actual product.

STRUCTURE:




DIAGRAM OF OPERATION:

Install Lithium Battery:

Unscrew the handle of flashlight DVR. Install the Lithium battery into the handle. Screw the handle of flashlight DVR back on.

Charging the Battery:

Remove the waterproof plug. Connect the power adapter to the flashlight DVR. The indicator light will be green while charging and turns off after fully charged.




Setting Date and Time:

If you find that the date/time of the video does not match your local date/time, the following steps will allow you to change the date and time:

1. Connect the Enforcer Flashlight DVR to the computer with the USB cable. Open My Computer and you will see the USB Mobile Disk folder icon.
2. Insert the CD in to the CD-ROM drive.
3. Open the CD, copy the "getsystemTime.exe" file to the Mobile Disk folder in the in the DVR Flashlight.
4. Once the "getsystemTime.exe" file is copied to the Mobile Disk folder, double click "getsystemTime.exe", the system will automatically update the date and time.

Use as a Flashlight:

Press the Light button once, bright LED light; Press again, low-light LED lights; Press a third time to turn off the LEDs.




FORMATTING MEMORY:

It is highly recommended to use the software on the CD provided to format The Enforcer's built-in memory. Using the functions of a Windows PC system to format The Enforcer will alter certain values, causing video file storage time to become slower. Follow the instruction below to format:


1. Insert the software CD provided into your computer's CD drive and search your CD drive for a file named "UDiskFormat.exe" and double-click on this file:



2. In the dialogue window, enter the disk drive name that The Enforcer is given when it is connected to your computer, e.g., H:/, G:/, etc. (open "My Computer" to locate the disk drive name):



3. Click "Format" to format the memory or "Exit" to close.



SPECIFICATIONS

Enforcer Flashlight DVR	Items	GD2716
	Imaging Sensor	1/4 inch Color CMOS
	Video Resolution	640 x 840
	View Angle	56°
	Video Format	.AVI
	Video File Size	> 15M Byte/minute
	View Resolution	640 x 840 (VGA)
	Storage Medium	2G built-in Memory
	Power Supply	Li-battery (3.7V/2000mAH)
	Charge Time	4 hours (max.)
	Data Transmission	USB 2.0
	Work Time	3.5 hours (min.)
	LED Light Power	1 W
	LED Light Color Temperature	>5500K
	Waterproof Capacity	IP65
	Consumption Current (max.)	560mA
	Charge Current	>800mA
	Dimensions (W x D x H)	191 x 56 x 56 (mm)
	Weight (approximate)	300g
	Operating Temperature	0° C~ + 50° C
	Operating Humidity	15~85%RH

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTIONS

- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Turn off the camera if the system is not in use.
- Do not put the battery in fire, water or near heat.
- Do not use the battery in heat or near places of high temperature.
- Do not use metal objects to connect the polarities of the battery.
- Do not open the battery.
- When not using the device for long periods of time, please remove the battery and store in a cool, dry place.

EU Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

